



SYSTEM OF NARCOTICS IDENTIFICATION

INSTRUCTIONS FOR USE


TEST Y - CANNABIS TYPIFICATION

FOR: THC and CBD Determination

Test Function

1. This reagent system presumptively distinguishes between THC and CBD content in dried plant material, edibles and oils.

How to Use Test Y

1. Remove clip and insert sample into test pack in an amount that would fit inside this circle. 
2. Sample should be no more than 2-4 small leaf fragments.
3. If using oils or edibles, only a small dab is necessary.
4. Reseal with clip and tap gently to assure material falls to the bottom of the pouch.
5. With the printed side of the test pouch facing you, break both ampules by squeezing the center of the ampule with the tips of the thumb and forefinger. Agitate gently and observe the color.

Interpretation of Resulting Colors

1. Agitate for one minute, and observe color development.
2. A blue color indicates the presence of THC above a 1% value. A pink color indicates CBD and that THC is below a 1% value.
3. A purple color indicates too much sample and test should be run again with less sample.

CAUTION

- A. Since these tests contain strong acids, it is suggested that Test F - Acid Neutralizer be used after testing and before disposal.
- B. Before discarding used test packs, remove clip and add one measure of acid neutralizer from Test F.
- C. Add slowly to prevent bubbling over.
- D. DO NOT reseal the test pouch until effervescence has completely stopped.
- E. Reseal pouch with clip and discard in a tamper-free disposal unit.
- F. No attempt should be made to crush the glass particles after the ampoules are broken.
- G. Antidote: In case of contact, immediately flush eyes or skin with water for at least 15 minutes while removing contaminated clothing and shoes. If swallowed, do not give emetics. Contact a physician.



13386 International Parkway
Jacksonville, Florida 32218
904.347.1200 FAX: 904.741.5407
© 2021 Safariland, LLC

A Brand of the Safariland Group